

# AquaMas<sup>®</sup> Flow Systems

## PC-V

CENTRIFUGAL SUMP PUMPS

INSTRUCTION for INSTALLATION, OPERATION & MAINTENANCE



Instructions for Installation, Operation and Maintenance.

M ve N Paz. Arař. Rekl. Kuy. ve Müh Hizm. Ltd. Őti.

All rights reserved. Can not be copied or reproduced for any purpose without permission.  
Subject in the manual can be changed without any prior notice.

This manual is intended to be a reference guide for users of pumps providing information on

Pump installation and maintenance instructions,  
Pumps start-up, operation and shut - down procedures.

## IDENTIFICATION OF SAFETY AND WARNING SYMBOLS



Safety instructions in this manual which could cause danger to life if not observed.



The presence of a dangerous electric current.



Non – observance to this warning could damage the machine or affect its functions.

## GENERAL INSTRUCTIONS




- **This manual should be kept in a safe place and ALWAYS be available to the QUALIFIED operating and maintenance personnel responsible for the safe operation and maintenance of the pumps.**

- Qualified personnel should be experienced and knowledgeable of safety standards.
- To avoid faulty operation and malfunctioning of pumps the instructions in this manual are to be CAREFULLY studied and followed at all stages of the pump installation and operating life.
- The user is responsible for ensuring that inspection and installation are carried out by authorized and qualified personnel who have studied this manual carefully.
- The pump should be used ONLY in the operating conditions given on the order for which the pump and materials of the construction have been selected and tested.
- If the pump is to be used for a different application please contact sales office or representative of the manufacturer. AquaMas Flow Systems refuses to assume any responsibility if the pump used for different applications without prior written permission.
- If the pump is not to be installed and operated soon after arrival, it should be stored in a clean and dry place with moderate changes in ambient temperature. Extreme low or high temperatures may severely damage the pump unless suitable precautions are taken. The user is responsible for the verification of the ambient conditions where the pump will be stored or installed.
- AquaMas Flow Systems does not guarantee repairs or alterations done by user or other unauthorized personnel. The use of original spare parts and accessories authorized by manufacturer will ensure safety.
- This manual does not take into account any site safety regulation, which may apply.

## SAFETY INSTRUCTIONS



Strictly obey to the following instructions to prevent personal injuries and/or equipment damages:

- Pump should be used only in the specified operating conditions.
  - Any weight, stressor strains on the piping system should not be transmitted to the pump.
  - Electrical connections on the motor or accessories must always be carried out by authorized personnel and in accordance to the local codes.
  - Any work on the pump should be only carried out when the unit has been brought to standstill.
- 
- **Always disconnect the power to the motor and make sure not be switched on accidentally before working on the pump or removing the pump from installation.**
  - Any work on the pump should be carried out by at least two persons.
  - When approaching the pump always be properly dressed and/or wear safety equipment suitable for the work to be done.
  - Do not work on the pump when it is hot.
  - Do not touch the pump or piping with temperatures higher than 80 °C. User must take suitable precaution to warn the persons (e.g. using warning signs, barrier).
  - Always be careful when working on pumps that handling dangerous liquids (e.g. acids or hazardous fluids).
  - Do not work on the pump when the pump and piping connected to the pump are under pressure.
  - After completion of the work always fix the safety guards back in places previously removed.
  - Do not run the pump in the wrong direction of rotation.
  - Do not insert hands or fingers into the pump openings or holes.
  - Do not step on the pump and/or piping connected to the pump.

# PC-V PUMPS

## A- GENERAL

### A1- Pump description

•PC-V series pumps are vertical centrifugal sump pumps.


### A2- Applications

PC-V series pumps are suitable for sewage or dirty and temperatures up to 90°C. The main application areas, among others, are:


- General wastewater supply, irrigation,
- Pressurized water supply,
- Circulation,
- Industry,
- Power plants.

### A3- Pump Designation

Pump type  
Discharge nozzle (DN in mm)  
Nominal impeller diameter



### A4- Pump Nameplate



- 1- Pump Type and Size
- 2- Production Year
- 3- Serial No
- 4- Capacity
- 5- Head
- 6- Motor Power
- 7- Impeller Diameter
- 8- Speed
- 9- Direction of Rotation

### A5- Technical Data

Speed	: up to 1500rpm
Discharge Nozzle	: DN 40 up to 300 mm
Discharge Flanges	: EN1092-2 / FN 16
Operating Temperature	: -10 °C up to 90 °C
Ambient Temperature (max)	: 40 °C

## B- UNCRATING, TRANSPORT AND STORAGE

### B1- Uncrating

- ☒ Upon receipt verify that the goods received are in exact compliance with that listed on the packing list.
- ☒ Check that no visible damage exists on the crate that could have occurred during transportation.
- ☒ Carefully remove the packaging material and check that pump and accessories (if any) are free from any markings, scratches and damages, which may have occurred during transportation.
- ☒ In the event of damage report this immediately to AquaMas Flow Systems's service department and to the transport company.

### B2- Transport

#### B2.1- General recommendations




- ☒ Existing regulations for the prevention of accidents must be followed.
- ☒ Wearing of gloves, hard-toed boots and hard hats is obligatory for all transport works.
- ☒ Wooden cases, crates, pallets or boxes may be unloaded with fork-lift trucks or using hoisting slings, depending on their size, weight and construction.

#### B2.2- Lifting

- ☒ Prior to lifting and moving the pump or pump and motor on a common base plate find out the following:
  - ☒ Total weight and center of gravity
  - ☒ Maximum outside dimensions
  - ☒ Lifting points location
- ☒ The load-bearing capacity must be proper to the weight of the pump or the pump set.
- ☒ The pump or pump set must always be raised and transported in horizontal position.
- ☒ It is absolutely forbidden to stand beneath or nearby a raised load.
- ☒ A load should never remain in a raised position for longer than necessary.
- ☒ Accelerating and braking during the lifting process must be performed such that there is no danger to persons.

When lifting the pump or complete pump set lift them as shown in below to avoid any distortion (especially do not use the motor eyebolt for carrying the complete unit).



### B3- Storage

- ☒ If the pump is not to be installed and operated soon after arrival, store the pump in a clean, dry and frost-free place with moderate changes in ambient temperature.
- ☒ If the pump has regreaseable bearings, pump extra grease on bearings to prevent moisture from entering around the shaft.
- ☒ To prevent the pump from moisture, dust, dirt and foreign materials suitable steps should be taken.
- ☒ The pump shaft should be revolved periodically (e.g. once a week) to prevent pitting of the bearing surfaces and the pump from seizing up.

## C- INSTALLATION ON SITE

### **ATTENTION** Installation has to be carried out in accordance with EN 60204-1.

The pump should only be installed, levelled up and aligned by skilled personnel. Incorrect installation on defective foundation could result in troubles. This would not be covered by the warranty.

#### C1- Bare Shaft Pump

- ☒ If the pump has been supplied without electric motor and coupling it is necessary to select a proper motor and coupling before proceeding to the installation of the unit.
- ☒ The following considerations must be taken into account for selection of motor:
  - ☒ Maximum power absorbed by the pump over the total operating range,
  - ☒ Pump operating speed,
  - ☒ Available power (frequency, voltage, etc.)
  - ☒ Motor type (TEFC, exproof, etc.)
  - ☒ Motor mounting position (foot mounted, flange mounted, horizontal, vertical, etc.)
- ☒ When selecting coupling nominal motor power and operating speed must be taken into account.

#### C2- Preparation For Installation

Before installing the pump

- ☒ Clean the discharge flanges thoroughly.
- ☒ Remove the protective coating from the pump shaft.
- ☒ If the pump has been in temporary storage remove all the grease from the bearings with grease lubricated or remove the oil from the bearing house if the pump is oil-lubricated, then clean the bearings with a suitable cleaning fluid and relubricate ( **NOTE:** This is not necessary for the pumps with life time grease lubricated bearings).

#### C3- Installation Site

**ATTENTION** ☒ The pump must be installed in a frost and dust-free, well-ventilated and non-explosive environment.

- ☒ The pump should be installed such that there is space for access, ventilation, maintenance and there is sufficient space above the pump for it to be lifted.

##### C3.1- Foundation

- ATTENTION** ☒ The greatest care must be taken in preparing the foundation and mounting the pump set. Incorrect installation will result in premature wear of pump components and break down of the pump.
- ☒ The foundation should be heavy enough to reduce vibrations and rigid enough to avoid any twisting or misalignment. Make sure the concrete foundation has set firm and solid before mounting the pumpset. The surface of the foundation should be truly horizontal and perfectly flat.

## C4- Connecting The Piping

### C4.1- General

**ATTENTION** ❑ **Never use the pump as an anchorage point or as a carrier for the piping.**

❑ The pipes should be supported very near the pump. It must be checked that any weight, stress or strains on the piping system should not be transmitted to the pump. Therefore after completing the piping installation, the bolt and connection on the discharge nozzle must be loosened to ensure that there is not any stress on the piping system to the pump.

❑ **The nominal sizes of the pump discharge nozzle are no guide to the correct sizes of the discharge piping.** The nominal bores of the pipes should be same as or greater than those of the pump nozzles. Never use pipes or accessories which have smaller bore than the pump nozzles. Particularly strainers, filters and non return valves must be preferred with larger free transition areas. In general the flow velocities should not exceed 3 m/s in the discharge piping.

❑ Pipe joints should be by means of flanges with flange gaskets of proper size and material. Flange gasket must be centered between the flange bolts in a such way that there is no interference with the flow of the liquid.

❑ Thermal expansions of the pipework and excessive vibrations should be accommodated by suitable means so as not to impose any extra load on the pump.

❑ Prevent impurities such as welding beads, scale, sand and tow might be left in pipes while production of the piping system harms the pump. Seal the pump nozzles by means of blind gasket to stop impurities get in the pump. After assembling the system all the piping parts must be disassembled, thoroughly cleaned, painted and reassembled again.

### C4.2- Discharge piping

❑ A control valve should be installed in the discharge pipe, as close to the pump as possible, to regulate the required flow and head.


❑ If the total head of the pump exceeds 10 meters or if discharge line is of appreciable length a non return valve should be installed between the pump and isolating valve on the discharge line to protect the pump against water hammer and reverse flow on shut down.

### C4.3- Auxiliary pipe connections and accessories

❑ Depending on the application auxiliary pipe connections (for cooling, sealing and flushing of seal, drainage etc. necessary for the pumping system) and/or accessories to check the operating conditions (pressure gages, temperature gages etc.) may be made up and laid.

❑ Pressure and vacuum gauges must be properly anchored and connected at the measuring points located on the pump flanges by means of or on the pipes close to the flanges approximately 8 mm diameter tubing with pig tail configuration to lessen pressure fluctuation. For safety purposes isolating and vent valves should be fitted before the gages.

❑ Cooling, sealing and flushing of seal piping must be connected only to the designated connections located on the pump .



#### C4.4- Minimum flow

If there is a possibility of the pump having to operate at zero flow (against a closed discharge valve) or near the closed valve with almost no flow, then a minimum flow valve (or a by-pass check valve) must be installed on the discharge nozzle or on the discharge piping right after the pump but before the flow regulating valve. In cases where there is no such a valve operating the pump against close valve for a long time causes considerable damage on the pump since almost all the motor power is transformed into thermal energy which is absorbed by the pumped liquid.

#### C4.5- Electrical connections



**⊠ The electrical motors have to be built in accordance with EN 60034-1.**

**⊠ Enclosures of electrical motors and control systems on the pump unit shall as a minimum give protection in accordance with EN 60529 IP22. But in determining the degree of protection of enclosures of electrical motors and control systems on the pump unit the operating and environmental conditions must be taken into consideration.**

⊠ Electrical connection should be done by a qualified electrician. Current national regulation and motor manufacturer's instructions must be observed.

⊠ Take all safety precautions listed in "Safety instructions". Disconnect all power supplies prior to doing any work.

⊠ The supply cable must be laid in such a way that it never touches the pipework, pump and motor casing.

⊠ Check voltage, phase and frequency on motor nameplate with the mains.

⊠ The electric motor must be protected against overloading by means of circuit breakers and/or fuses. Circuit breakers and fuses must be selected in accordance with full load amperage of the motor appearing on the motor rating plate.

⊠ It is recommended to use PTC (passive thermal control) on motor, but this is optional depending on customer requirement. In case of using PTC, these should be connected via corresponding terminals in the terminal box and the PTC should be connected to the thermal trip mechanism.


⊠ Prior to connecting the electrical wiring rotate the pump shaft by hand to make sure rotor rotates easily.

⊠ Connect the electrical wiring in accordance with local electrical codes and make sure to ground the motor.


⊠ The connection diagram can be found in the terminal box of the motor or in the instruction manual.

⊠ The main connection on the tagboard depends on the nominal power of the motor, the power supply and the type of connection. The necessary connection of the bridges in the terminal box is shown in the following


Type of switch	Motor Power $P_N \leq 4 \text{ kW}$	Motor Power $P_N > 4 \text{ kW}$
	power supply 3 ~ 400 V	power supply 3 ~ 400 V
direct	Y-connection	⊠-connection
Y/⊠-start	Impossible	Remove connecting bridges



Δ - connection.



Y-connection



Y/Δ-start



**ATTENTION**

In the case of three-phase induction motors with Y- $\Delta$  connection it must be ensured that the change-over points between star and delta follow on from one another very quickly. **Longer change-over times may result in pump damage.**

Motor Power	Y - set time
$\leq$ 30 kW	< 3 sec
> 30 kW	> 5 sec



Fix the safety guards back in places. Do not operate the pump before doing so. This is a necessity for security and job safety.

## D- START UP / SHUT DOWN

### D1- Preparation

D1.1- Lubrication control

Since the ball bearing of pump is generally life-time grease lubricated type it is maintenance free.

D1.2- Checking the direction of rotation

**PC-V** type pumps rotate in clockwise when it is looked from coupling to the pump. This direction is already indicated on the pump nameplate by an arrow. Check this by switching the pump on, then off again immediately. Fit the coupling guard back in place if you took it out.

### D2- Start Up The Pump

Check if the shut off valve in discharge line is closed. Open flushing water system.

Switch on the circuit breaker and run the motor.

Wait until the motor reaches the full speed (on star-delta running motors wait until it switches on delta).

Open the discharge valve slowly while watching the ampermeter on the control panel (if the discharge line is empty do not turn on the valve fully open on first start up. Turn it on slowly to maintain the value on the ampermeter is under the rated current value of the motor).

When the valve is fully open, check the pressure on the manometer and see it is the same with the duty point pressure. If the pressure on the pressure gauge is lower than duty point pressure brings them to the duty point value by slightly closing the valve. If it is higher value, check your installation, particularly head again.

**ATTENTION**

**The pump should be shut down at once and the trouble should be corrected if the pump is running at its rated speed and found any of the following faults:**

- Pump doesn't deliver any water,
- Pump doesn't deliver enough water,
- Flow is going down,
- Discharge pressure is not enough,
- Driver overloaded,
- Vibration on pump,
- High noise level,
- Bearing overheating

### D3- Shut Down The Pump

- ☒ Slowly close the shut-off valve in the discharge line.
- ☒ You may shut down the pump without closing the shut-off valve if there is a device for water hammer protection on the discharge line or the water hammer is not a considerable level.
- ☒ Switch off the driver. Ensure the pump set runs down smoothly and quietly to a standstill.
- ☒ Shut off external sealing liquid supply, if supplied, to relieve stuffing box pressure.
- ☒ If the set is to remain out of services for a long time close the shut-off valve in the suction pipe. Close off the auxiliary connections. In the event of frost and/or prolonged standstill, drain the pump or otherwise protect against freezing.

### D4- Checks to be Made While The Pump is Running

- ☒ The pump must run smoothly, quietly and free from vibration at all times.
- ☒ The pump must never run dry.
- ☒ Never run the pump for along period against a closed discharge valve (at zero flow).
- ☒ The bearing temperature may exceed the ambient temperature by up to 50° C. But must never rise above 80° C.
- ☒ The valves in the auxiliary lines must remain open while the pump is running.
- ☒ The flexible coupling elements should be regularly checked and replaced as soon as they are shown signs of wear.
- ☒ Occasionally check the motor current. Stop motor if the amperage is higher than usual; there may be jamming or friction in the pump. Make the necessary mechanical and electrical checks.
- ☒ Stand-By pumps should be run for a short time at least once a week to ensure they are in constant readiness for operation. Check the integrity of auxiliary connections.

## E- LUBRICATION

The pump shaft is supported by water lubricated sleeve bearing in the column pipe casing and grease lubricated ball bearing on the delivery side.

### Periods of re-greasing

The pump bearings are filled up with grease before dispatch.

**Ball bearing** : The grease should be changed after 3000 hours or two years at the longest operation. Use a high quality lithium soap grease.

**ATTENTION** ☒ The bearing temperature may exceed the ambient temperature by up to 50° C. But never rise above 80° C.

- ☒ Do not reuse the bearings following disassembly for maintenance purposes.

## F- DISASSEMBLY, REPAIR AND REASSEMBLY



Before starting work on the pumpset, make sure it is disconnected from the mains and can not be switched on accidentally.



Follow the safety precaution measures outlined in "safety instructions".

### F1- Disassembly

Close all valves in the suctions and discharge lines, and drain the pump by opening the drain plugs (230). Detach pump suction and discharge flanges and all auxiliary supply lines, disconnect the pump from the piping system.

Disconnect the motor (600) from the motor pedestal (011).

Remove coupling guard and other safety guards (See **section M** for guards).

Unscrew the anchor bolts of pump support plate (016).

Place the pump on its motor pedestal (011) vertically.

Before dismantling the pump, number or mark the stage casings, suction and discharge casings and also mark their position in relation to each other to ensure proper reassembly.

Disconnect the filter (013) from the suction casing (004).

Disconnect the suction casing (003) from the stage casing (006).

Unscrew the impeller nuts (064).

Remove in sequence impellers (050), stage casings (006) together with diffusers (015) and final stage diffuser and keys (210).

Unscrew the bolts (320) and disconnect the column pipe (013).

Unscrew the allen bolts (350) and remove the coupling (091).

Disconnect the column pipe (014) from the discharge casing (005).

Unscrew the stud (306) and disconnect the discharge casing (005).

**Remark** : If the pump has mechanical seal, first disconnect the mechanical seal cover (048) from the discharge casing, and then disconnect the discharge casing from the bearing housing (030).

Place the pump horizontally for removing the rest of the parts of the pump.

Disconnect the motor pedestal (011).

Disconnect the coupling (pump) (090) from the shaft using a pull-off device and remove key (212).

Disconnect the bearing cover (034).

Carefully drive the shaft and bearing (200) out of the bearing housing with gentle taps on the end of shaft.

Pull of the bearing (200) from the shaft.

Remove the spacer sleeve (067).

### F2- REASSEMBLY

Reassemble in accordance with standard engineering practice. You may find the attached drawings useful.

Clean all the parts, replace damaged or worn-out ones.

Coat the seats and screw connections with graphite, silicon or similar slippery substance before assembly.

If you can not find any of the above you may use oil instead (except the pumps for drinking water).

#### **ATTENTION**

**Never use the old o-rings and make sure the new o-rings are the same size as the old ones.**

Reassemble the pump in reverse sequence to dismantling.

## G- SPARE PARTS

- ☒ STANDART POMPA guarantees to supply the spare parts for PC-V type pumps for 10 years. You can provide any spare parts easily.
- ☒ Lets us know the following details on the name-plate, when you order spare parts.

**Pump Type and Size** : (PC-V 150 - 315)  
**Motor power and Speed** : (15 kW - 1500 rpm)  
**Prod. Year and Serial Number** : (..... - .....)  
**Capacity and Head** : (..... - .....)

- ☒ If you prefer to have spare parts in your stock, we recommed you to have the following quantities for a two years operation depending on the number of same type of pumps

Part No	Part Name	Number of pumps in the system							
		2	3	4	5	6-7	8-9	10+	
060	Shaft (Incl. keys)	1	1	2	2	2	3	30%	
050	Impeller	1xs(*)	1xs	1xs	2xs	2xs	3xs	30%	
049.1, 049.2	Sleeve bearing	1	1	2	2	3	4	50%	
201	Ball bearing	1	1	2	2	3	4	50%	
420	O-Rings for casing	s + 1	s + 1	s + 1	2s + 1	2s + 1	3s + 1	150%	
046, 036	Shaft Protecting Sleeve	2	2	3	3	3	4	40%	

## H- FAULTS, CAUSES AND REMEDIES

In this section you will find operating faults which may arise, and their causes, and suggested remedies.

**ATTENTION** Before remedying operating faults, check all measuring instruments used for reliability and accuracy

FAULTS	POSSIBLE CAUSES
Pump doesn't deliver any water after start-up	1-5-7-10-11-13
Flow is going down or no flow at all	2-3-8-14
Driver overloaded	9-12-17-18-19-27-28
Bearings overheating	19-20-21-22-24
Vibration on pump	15-16-19-23-25
Noise level is high	4-6-26

	<b>POSSIBLE CAUSES</b>	<b>REMEDIES</b>
1	There may be air existing in pump or suction pipe	Fill pump and suction pipe completely with liquid and repeat the priming procedure.
2	Ingress of air through shaft seal, suction pipe or suction port. Pump lifts liquid with air	Check for leaks in suction pipe joints and fittings. Check shaft seal if necessary increase the pressure of sealing liquid. Check the dept of suction pipe or foot valve in the liquid and if necessary increase the depth of them.
3	Air pocket in the suction pipe.	Check the slope of the suction line make sure that there is no reason for formation of air pockets
4	There is air in liquid	Suction pipe is not submerged enough creating vortex. Check liquid level in suction tank or increase the depth of suction pipe or foot valve in the liquid.
5	Too much suction lift	If no obstruction at inlet check the friction losses of suction line, larger piping may correct condition. If static lift is too high, the liquid level in the suction tank must be raised or the pump lowered.
6	Pump is working at cavitation conditions	NPSH available is too low. Check liquid level in suction tank, check suction line for excessive friction losses. Check isolating valve in suction line to make sure it is completely open. If necessary increase suction head on pump by lowering the pump.
7	Insufficient manometric head.	The actual total head is higher than that originally specified. Check the geodetic total head and friction losses in the discharge line. Larger piping may correct the condition. Check that valves are fully open.
8	Increase at total manometric head.	Check that valves are fully open. Check that there is any obstruction in discharge pipe.
9	Pump is operating at lower manometric head.	The actual total head is lower than that originally specified. Machine impeller outer diameter to size advised by supplier.
10	Reverse rotation.	Check motor rotation with directional arrow on pump casing or nameplate.
11	Speed is too low.	Check the supply voltage and frequency or motor may have open phase.
12	Speed is too high.	If possible decrease the pump rotational speed or turn down the impeller outer diameter to size advised by supplier.
13	Impeller or check valve or strainer is clogged.	Clean the impeller or check valve or strainer
14	Impeller or strainer is clogged partially.	Clean the impeller or strainer.
15	Partially clogged impeller.	Clean the impeller.
16	Worn out and defected impeller.	Replace impeller.
17	Mechanical frictions inside the pump.	Check pump rotor for any rotor obstruction or deformation.
18	Excess tightened soft packing.	Loosen the nuts of the packing gland.
19	Bad coupling alignment.	Check the coupling rubber and realign the coupling.
20	Bearing covers are too tight.	Check and make necessary modification on the cover.
21	The pumped flow is less than the minimum flow required.	Increase the flow. If necessary use by-pass recirculating valve or line.
22	Existence of excess grease.	Remove excess grease.
23	Oblique shaft.	Check the shaft and replace it if necessary.
24	Insufficient lubrication or lubricating oil/grease dirty, contaminated.	Check the amount of oil/grease. Clean the bearings and bearing housing and relubricate
25	Unbalanced rotating parts.	Check the balance of the rotating parts.
26	Pump runs out of duty range.	Check the values of operating point.
27	The density or viscosity of the liquid pumped is higher than that originally specified.	Use a more powerful motor.
28	Defects in motor.	Check any motor defects. The motor may not be ventilated properly due to a poor location.

## I- TIGHTENING TORQUES


Tightening Torques		
Thread Diameter	Tightening Torque max (N.m)	
	Property Classes	
	8.8	10.9
M4	3.0	4.4
M5	5.9	8.7
M6	10	15
M8	25	36
M10	49	72
M12	85	125
M14	135	200
M16	210	310
M18	300	430
M20	425	610
M22	580	820
M24	730	1050
M27	1100	1550
M30	1450	2100
M33	1970	2770
M36	2530	3560

## J- EXPECTED NOISE VALUES

Power of Motor $P_N$ (kW)	Sound pressure level (dB <sub>A</sub> ) * (Pump with motor)	
	1450 rpm	2900 rpm
< 0.55	60	64
0.75	60	66
1.1	62	66
1.5	63	68
2.2	64	69
3	65	70
4	66	71
5.5	67	73
7.5	69	74
11	70	76
15	72	77
18.5	73	78
22	74	79
30	75	81
37	75	82
45	76	82
55	77	84
75	78	85
90	79	85
110	80	86
132	80	86
160	80	86

(\*) Without protective sound hood, measured at a distance of 1 m directly above the driven pump, in a free space above a sound reflecting surface.

K- SECTIONAL DRAWING




001	Volute Casing
003	Casing Cover
011	Bottom Cover
012	Motor Pedestal
031	Bearing Housing
035	Bearing Cover
036	Shaft Protecting Sleeve
037	Bottom Bearing Cover
046	Shaft Protecting Sleeve
049.2	Sleeve Bearing (bottom)
049.1	Sleeve Bearing (intermediate)
050	Impeller
051	Intermediate Bearing Housing
060	Shaft
065	Impeller Nut
087	Flexible Coupling
088	Coupling
101	Column Pipe
102	Suction Bowl
201	Double Row Ball Bearing
210	Impeller Key
240	Discharge Pipe
393	Shaft Nut
420	O-Ring
600	Electric Motor
801	Base Plate







All rights reserved. Can not be copied or reproduced for any purpose without permission.  
Subject in the manual can be changed without any prior notice.



M ve N Paz. Arař. Müh. Ltd. Őti  
Perpa Ticaret Merkezi B Blok Kat 8 No. 1017  
Okmeydanı - İstanbul / TURKEY  
Tel: +90 212 320 76 32 / 33 Fax: +90 212 221 76 53  
e-mail: [info@aquamas.com](mailto:info@aquamas.com) - [www.aquamas.com](http://www.aquamas.com)